



# Parrot AR.Drone 2.0 Propeller and Gear Replacement

Use this guide to replace, propellers, shafts, and gears on a Parrot AR.Drone 2.0.

Written By: David Hoyt



## INTRODUCTION

Use this guide to replace, propellers, shafts, and gears on a Parrot AR.Drone 2.0.

AR.Drone 2.0 spare parts and mounting tools are available from [several Parrot retailers](#).

[video: <http://youtu.be/Qx01V37QbnY>]

---



## TOOLS:


- [iFixit Opening Tools](#) (1)
-

## Step 1 — Propeller and Gear



- Remove the foam body.

## Step 2



- Disconnect the battery by pulling the two red wires apart.
- Remove the battery by releasing the battery retaining straps.

## Step 3



- Remove the small retaining clip using a plastic opening tool.

ⓘ Be careful as these clips can fly off and can be difficult to find.

## Step 4



- The propeller, gear, and rod can be removed by simply lifting them off the motor.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-17 10:49:48 AM.